OPERATING MANUAL

GLP/GDP20UX-35UX (A7S1) Internal Combustion Counterbalanced Forklift Truck

PART NO. 550216339

1/20

SPECIAL EQUIPMEN	DRIVE TIRE SIZE	CARRIAGE TYPE	MAST LIFT HEIGHT	TRANSMISSION TYPE	ENGINE MODEL	LIFT TRUCK MODEL
SPECIAL EQUIPMENT OR ATTACHMENTS	STEERING TIRE SIZE	GROUP NUMBER	GROUP NUMBER	SERIAL NUMBER	SERIAL NUMBER	SERIAL NUMBER

tions. 😽 is a registered copyright. YALE and VERACITOR are Registered Trademarks of Hyster-Yale Group, Inc. PREMIER, and @ are Trademarks in the United States and certain jurisdic-

© Yale Material Handling Corporation 2020. All Rights Reserved.



Foreword

To OWNERS, USERS, and OPERATORS:

The safe and efficient operation of a lift truck requires skill and alertness on the part of the operator. To develop the skill required, the operator must:

- Receive training in the proper operation of THIS lift truck.
- Understand any potential hazards that may exist in the work place where the lift truck is intended to be used.
- Understand the capabilities and limitations of the lift truck.
- Become familiar with the construction of the lift truck and see that it is maintained in good condition.
- Read and properly understand the warnings, instructions, and operating procedures in this manual.

In addition, a qualified person, experienced in lift truck operation, must guide a new operator through several driving and load handling operations before the new operator attempts to operate the lift truck alone.

It is the responsibility of the employer to make sure that the operator can see, hear, and has the physical and mental ability to operate the equipment safely.

NOTE: A comprehensive operator training program is available from **Yale** Company. For further details, contact your dealer for **Yale** lift trucks.

This **Operating Manual** is the original instruction and contains information necessary for the operation and maintenance of a basic lift truck. Optional equipment is sometimes installed that can change some operating characteristics described in this manual. Make sure the necessary instructions are available and understood before operating the lift truck.

Some of the components and systems described in this **Operating Manual** will **NOT** be installed on your unit. If you have a question about any item described, contact your dealer for **Yale** lift trucks.



The following additional information is provided as specified in Machinery Directive 98/37 EC and/or 2006/42/EC:

- Dimensional Details: Certain information is shown on the truck Nameplate. For additional dimensional details on this or any other specific truck, consult your dealer.
- Noise Levels: In accordance with standards EN 12053 and EN ISO 4871, the equivalent sound pressure level (Lpaz) at the operator position is in the range of 84.0 dB(A). This may vary depending on truck options.
- Human Vibration (Whole Body and Hand-Arm Vibration).

Note: The whole-body vibration level is measured according to standard EN 13059 which contains specific test criteria (load, speed, roadway surface, etc.). Worksite vibration levels may vary depending on actual operating and surface conditions.

Whole-body vibration:

— Measured whole-body vibration at the operator position, based upon standard production truck with full-suspension or comfort-suspension seat is listed below.

- Declared whole-body vibration emission value is in accordance with EN 12096.
- Full-suspension seat measured vibration emission value $a_{w,z} = 0.8 \text{ m/s}^2$
- Uncertainty, $K = 0.2 \text{ m/s}^2$
- Values determined according to EN 13059

Hand-arm vibration:

- Hand-arm vibration emission value = < 2.5 m/s²
- Hazardous Atmosphere: Before any truck within the European Community can be operated in a Potentially Explosive Atmosphere, it is necessary that the truck is suitably converted for the application. Conversions should only be carried out by a Yale approved supplier. Confirmation of the conversion can be made by referring to the truck Declaration of Conformity which will confirm compliance with European Directive 94/9/ce. If you are in doubt, please contact your Yale dealer for assistance.



Disposal of lubricants and fluids must meet local environmental regulations.



- Manufacturer: Yale Europe, Centennial House, Frimley Business Park, Frimley, Surry GU16 7SG, United King-
- certificate which complies with Machinery Directive 2006/42/EC this section for a sample EC Declaration of Conformity EC Declaration of Conformity certificate. See the end of The EC Conformity: Each lift truck ships with a unique

applicable, product/option meets the requirements outlined subject to Radio Equipment Directive 2014/53/EU. Where in this Directive **NOTE:** Some products have options for equipment that are

NOTE: Yale lift trucks are not intended for use on public

information in this manual. **NOTE:** The following symbols and words indicate safety

WARNING

could result in death or serious injury. Indicates a hazardous situation which, if not avoided,



CAUTION

damage could result in minor or moderate injury and property Indicates a hazardous situation which, if not avoided,

ground background. The CAUTION symbol is on yellow back-On the lift truck, the WARNING symbol is on orange

Foreword



Atmospheric Conditions

This range of fork lift trucks is designed to work in the following atmospheric conditions:

Relative humidity:	Altitude:	Lowest ambient temperature for trucks intended for use in normal outdoor conditions:	Lowest ambient temperature for trucks intended for use in normal indoor conditions:	Maximum ambient temperature, short term (up to 1 hr):	Average ambient temperature for continuous duty:
From 30% to 95% (non-condensing)	Up to 2000m	-20°C	+5°C	+40°C	+25°C



Truck Modification

Unauthorized truck modification is not permitted. To obtain authorization contact your **Yale** dealer.

Only in the event that the truck manufacturer is no longer in business and there is no successor in the interest of the business, the user may arrange for a modification or alteration to a powered industrial truck, provided, however, that the user shall:

- Arrange for the modification or alteration to be designed, tested, and implemented by an engineer(s) expert in industry trucks and their safety;
- 2. Maintain a permanent record of the design, test(s), and implementation of the modification or alteration;
- Approve and make appropriate changes to the capacity plate(s), decals, tags and instruction handbook;
- Affix a permanent and readily visible label to the truck stating the manner in which the truck has been modified or altered together with the date of modification or alteration, and the name and address of the organization that accomplished the tasks.

Introduction

This operation manual explains how to use a 2.0T-3.5T forklift truck correctly. It will instruct you how to perform maintenance in order to ensure good working order and maximize the truck's potential. All operators, service technicians, and supervisors should read this manual thoroughly before working with the forklift.

Product specifications in this manual may vary from your actual truck.

Please contact your sales agent or dealer if you have any questions or comments regarding this manual.



Table 1. Models and Configuration

Series	Model	Engine	Transmission
	GLP/GDP20 & 25UX	GLP/GDP20 & 25UX YANMAR 2.6 DSL (4TNE92)	Powershift 1 Speed Transmission
	GLP/GDP20 & 25UX	GLP/GDP20 & 25UX XINCHAI 2.67L DSL (490BPG)	Powershift 1 Speed Transmission
	GLP/GDP20 & 25UX	GLP/GDP20 & 25UX MITSUBISHI DSL (S4S-455)	Powershift 1 Speed Transmission
	GLP/GDP20 & 25UX	GLP/GDP20 & 25UX GCT 2.1L LPG Non Cert (K21)	Powershift 1 Speed Transmission
	GLP/GDP20 & 25UX	GLP/GDP20 & 25UX GCT 2.1L Gasoling Non Cert	Powershift 1 Speed Transmission
GLP/GDP25UX	GLP/GDP20 & 25UX	GLP/GDP20 & 25UX GCT 2.1L Bi-Fuel Non Cert	Powershift 1 Speed Transmission
	GLP/GDP20 & 25UX	GLP/GDP20 & 25UX GCT 2.5L LPG Non Cert	Powershift 1 Speed Transmission
	GLP/GDP20 & 25UX	GLP/GDP20 & 25UX GCT 2.5L Gasoline Non Cert	Powershift 1 Speed Transmission
	GLP/GDP20 & 25UX	GLP/GDP20 & 25UX GCT 2.5L Bi-Fuel Non Cert	Powershift 1 Speed Transmission
	GLP/GDP20 & 25UX PSI 2.4L LPG Cert	PSI 2.4L LPG Cert	Powershift 1 Speed Transmission
	GLP/GDP20 & 25UX PSI 2.4L Bi-Fuel Cert	PSI 2.4L Bi-Fuel Cert	Powershift 1 Speed Transmission



Table 1. Models and Configuration (Continued)

Series	Model	Engine	Transmission
	GLP/GDP30 & 35UX	GLP/GDP30 & 35UX XINCHAI 2.67L DSL (490BPG)	Powershift 1 Speed Transmission
	GLP/GDP30 & 35UX	GLP/GDP30 & 35UX MITSUBISHI DSL (S4S-455)	Powershift 1 Speed Transmission
	GLP/GDP30 & 35UX	GLP/GDP30 & 35UX Yanmar 3.0L DSL (4TNV94)	Powershift 1 Speed Transmission
	GLP/GDP30 & 35UX	GLP/GDP30 & 35UX Yanmar 3.3L DSL (4TNE98)	Powershift 1 Speed Transmission
	GLP/GDP30 & 35UX	GLP/GDP30 & 35UX GCT 2.1L LPG Non Cert (K21)	Powershift 1 Speed Transmission
GLP/GDP30 &	GLP/GDP30 & 35UX	GLP/GDP30 & 35UX GCT 2.1L Gasoline Non Cert	Powershift 1 Speed Transmission
GLP/GDP35UX	GLP/GDP30 & 35UX	GLP/GDP30 & 35UX GCT 2.1L Bi-Fuel Non Cert	Powershift 1 Speed Transmission
	GLP/GDP30 & 35UX GCT LPG Non Cert	GCT LPG Non Cert	Powershift 1 Speed Transmission
	GLP/GDP30 & 35UX	GLP/GDP30 & 35UX GCT 2.5L Gasoline Non Cert	Powershift 1 Speed Transmission
	GLP/GDP30 & 35UX	GLP/GDP30 & 35UX GCT 2.5L Bi-Fuel Non Cert	Powershift 1 Speed Transmission
	GLP/GDP30 & 35UX	PSI 2.4L LPG Cert	Powershift 1 Speed Transmission
	GLP/GDP30 & 35UX PSI 2.4L Bi-Fuel Cert	PSI 2.4L Bi-Fuel Cert	Powershift 1 Speed Transmission

Yale (E

EC DECLARATION OF CONFORMITY

WE YALE EUROPE

CENTENNIAL HOUSE

BUILDING 4.5

FRIMLEY BUSINESS PARK FRIMLEY, SURRY GU16 7SG

LINITED KINGDOM

UNITED KINGDO	M
DECLARE UNDER OUR SOLE RESPO	ONSIBILITY THAT THE MACHINE
CATEGORY: FORKLIFT IC ENGINE I	POWERED
TYPE	
SERIAL NUMBER(S)	
YEAR OF CONSTRUCTION	
	CHINERY DIRECTIVE 2006/42/EC. COMPLIANCE WITH BY MEETING THE TECHNICAL REQUIREMENTS OF JUDING EN ISO 3691-1
OTHER APPLICABLE DIRECTIVES: 2014/30/EU - EMC EMISSIONS 2000/14/EC - SOUND POWER I BY 2005/88/EC.	; FOR IC ENGINED FORKLIFT AS AMMENDED
B1 2003/06/EC.	TYPICAL VALUE dB
RESULTS OBTAINED BY FOLLOWIN REQUIREMENTS OF DIRECTIVE 200 TECHNICAL FILE CONTROLLED BY	GUARANTEED VALUE, dB EDURE: INTERNAL CONTROL OF PRODUCTION AND NG TEST PROCEDURE TEP 361, IN LINE WITH THE 10/14/EC THE ENGINEERING MANAGER, HYSTER-YALE UK AVON, NORTHERN IRELAND/NIJMEGEN, THE
NAME POSITION	PLANT MANAGER (BLOCK LETTERS)
SIGNATURE DATE	



	Contents	nts	
Foreword	_	TRANSPORTING AND LOADING-UNLOADING OF	
TO OWNERS, USERS, AND OPERATORS:	_	:	34
ATMOSPHERIC CONDITIONS	4	INSPECTION BEFORE OPERATION	35
TRUCK MODIFICATION	51	Checks With the Engine Stopped	35
INTRODUCTION	ΟΊ		36
Warning	1		36
Operating Devices and Operating Methods	14	Starting Procedure	37
LOAD BACKREST	25	Operating Techniques	8
SEAT ADJUSTMENT	26	LIFT TRUCK INTERLOCKS	38
OPERATOR PRESENCE SYSTEM	26	STARTING FORKLIFT TRUCK	39
SEAT BELT	27	RUNNING	40
OVERHEAD GUARD	27	LOADING	45
HOOD	27	STACKING	45
RADIATOR CAP AND COOLANT RESERVOIR	28	UNLOADING	46
FORK POSITION LOCK	28	STORAGE	47
BRAKE FLUID RESERVOIR	29	Periodic Maintenance	50
HYDRAULIC FLUID RESERVOIR CAP	29	PERIODIC MAINTENANCE REQUIREMENTS	50
Operating Instructions	30	:	50
USE OF NEW TRUCK	30	HYDRAULIC TRANSMISSION FORKLIFT TRUCK	55
RELATIONSHIP BETWEEN LOAD AND FORKLIFT		,	56
TRUCK STABILITY	30	PERIODIC MAINTENANCE	59
LOAD CENTER AND LOAD CURVE	3	FORKS	60
STABILITY AND CENTER OF GRAVITY	32	Forks, Remove	60
CAPACITY (WEIGHT AND LOAD CENTER)	33	Forks, Inspect	62

Forks, Inspect

Contents



106	Maintenance Register 106	99	Label for Load Curve Diagram (Demonstration) 99
105	Label for Adding Brake Oil	98	Data Plate for Fork Loading and Unloading Truck
105	Label for Seatbelt	97	Label of Notices for Use
104	Operator Restraint and Tip-Over Warning Label 104	97	Warning Label No One On or Under the Forks
104	Label for Fan Safety	97	LABELS
103	Label for Filling Fuel	95	DRAWING OF LUBRICATION SYSTEM
102	Mast Warning Label - Crush Point	95	Miscellaneous
102	Label for No Riders	92	TOWING
st 101	Label Do Not Stand Near or On Any Part of Mast 101	92	HANDLING
101	Label for Lifting 101	92	HOISTING FORKLIFT
100	Label for Tire Safety (Pneumatic Tire)	92	Hoisting, Handling, and Towing of Forklift Truck
100	Label for Adding Hydraulic Oil 100	65	PERIODIC MAINTENANCE TABLES
99	Label for Parking Brake Adjustment	65	Forks, Install



- Only drivers who have been trained and have an operator's license may drive the truck.
- Prior to driving the truck, inspect each control and warning device. If you discover damage or a defect, then do not operate the truck until it has been repaired.
- When handling a load, do not exceed the specified load capacity plate. The forks must be fully inserted under the load so that it is evenly positioned across the forks. Do not lift a load with only one fork.
- Starting, steering, driving, braking and stopping should be performed smoothly. Decrease speed when turning on wet or slippery surfaces.
- When traveling with a load, keep the load as low as possible and the mast tilted backwards.
- When driving on a slope, drive cautiously. When driving on a slope with a load, drive forward up the slope, and drive in reverse when descending the slope. Avoid turning on a slope. Do not engage in loading or unloading

- operations while the forklift truck is being driven on a slope.
- While driving, pay attention to pedestrians, obstacles, and potholes on road surfaces, and pay attention to the clearance above the forklift truck and load.
- No one may stand on the forks; the truck must not carry passengers.
- No standing or walking under the forks.
- The forklift truck and attachments shall not be operated from anywhere but the operator's seat.
- Do not move unsecured or loosely piled loads. Be cautious when moving larger loads.
- In the case of high-lift forklifts that lift higher than 3
 meters, pay attention to the possibility that the load
 above may fall. Take protective measures when necessary.



WARNING

- When operating a high-lift forklift truck, tilt the mast back as far as possible for transport. Tilt forward and back within the minimum range for loading and unloading operations.
- Be careful and drive slowly when driving on a loading dock or other potentially hazardous areas.
- When adding fuel, the driver must not be on the forklift truck, and the engine must be turned off. Do not ignite a flame when inspecting the battery or the fuel tank level.
- When a forklift truck equipped with attachments is being operated, it should always be operated as though loaded.
- Prior to exiting the forklift, lower the forks to the ground and put the direction control into neutral. Engage the parking brake. Turn off the engine. When parking on a slope, engage the parking brake. Place wheel chock to chock wheels.

- If a fault, such as hydraulic oil leaking, battery electrolyte leaking, etc. occurs, slowly drive to level ground and stop the truck, lower forks to ground, put direction control in neutral, engage park brake, and turn off engine. Contact authorized repair technician. Do not operate truck unless it has been properly repaired by trained technician.
- Solid, level surfaces, asphalt, or concrete road surfaces are the recommended operating surfaces for forklift trucks. When snow, ice, water, or other foreign matter has accumulated on the surface, do not operate until after the accumulated snow, ice, water, or other foreign matter has been completely removed.
- If the forklift breaks down, first move the forklift to a
 place where traffic will not be obstructed. If the breakdown was caused by the braking system or a steering
 system failure, then transport it using an appropriate
 transport forklift. If there was another cause, then use an
 appropriate towing forklift.



■ WARNING

- After removing the hood, the radiator cover plate, the overhead guard, the mast backrest, etc., do not operate the forklift.
- The forklift working site shall be adequately lit. While working at night, turn on the headlights. In addition, a sufficient light source should be allocated for the work.
- Contact the dealer for Yale forklift truck for forklift truck modifications.

Operating Devices and Operating Methods




Figure 1. Main Parts



Legend for Figure 1

STEER WHEEL	LOAD BACKREST MAST STEER WHEEL	FORK CARRIAGE	EOBK.
	10. HOOD	9. COUNTERWEIGHT	

Introduction to Instrument Panel

The instrument is used to indicate the working conditions of various critical systems of the forklift so that operators can quickly determine system failure prior to maintenance.

NOTE: The hour meter and optional weight meter share a digital display zone. When it is powered on, it displays the

hour counter. Press any key and displays the weight value and "kg" . At the same time, the hour meter funnel chart is off.






Figure 2. Display

B0990170



1. Steering Signal Indicator Light

Turn left light, the forklift's left turn signal works

2. Steering Signal Indicator Light

Turn right light, the forklift's right turn signal works

3. Oil-Water Separator Indicator Light (Diesel Truck)

When the key switch is in the start position, the light is on. When the engine starts, the light is off.

4. Oil Pressure Alert Indicator Light

goes out after the engine starts and the accelertor pedal is comes on when the ignition switch is set to ON. The light pressed This light indicates the pressure of the engine oil. The light

5. Engine Fault Indicator Light

Engine fault or malfunction

6. Glow Indicator Light (Diesel Truck)

After the idicator light goes out, turn the switch to the start The light comes on when the ignition switch is set to **ON**.

7. Parking Indicator Light

applied. Release the parking handle (hand brake handle). Parking indicator will illuminate when the parking brake is The parking indicator will go off.

8. Battery Charge Indicator Light

is pressed goes out after the engine starts and the accelerator pedal comes on when the ignition switch is set to ON. The lamp This lamp indicates the battery charge condition. The lamp

CAUTION

operation, the charging rate is low and should be checked immediately. If the light continues to stay lit or comes on during

9. Seat Belt Indicator Light

Seat belt not fastened and operator not in seat

10. Hour Meter Indicator

any key. Switch to display the weight of the goods after you press Displays the forklift running time when truck is operating.



11. Engine Coolant Temperature Indicator

Displays engine coolant temperature

12. Fuel Level Indicator

Displays the amount of remaining fuel in the tank.

13. Transmission Oil Temperature Malfunction Indicator Light

Red light will be **ON** when transmission oil temperature is too high.

14. Forward, Neutral, and Reverse Indicator

The direction lights will illuminate when the operator selects direction of travel. When the transmission is put in **NEU-TRAL**, the **N** illuminates and stays lit until transmission is not in **NEUTRAL**.

15. Air Filter Indicator

When illuminated, service the air filter.

16. Transmission Oil Temperature Indicator

Displays transmission oil temperature

See Figure 3.

WARNING

If any of the controls, instruments, levers, or pedals do not operate as described in the following tables, report the problem immediately. DO NOT operate the vehicle until the problem is corrected.





Figure 3. Controls and Switches (Sheet 1 of 2)





- LIFT LEVER
- <u>-</u> SIGNAL LIGHT LEVER
- 3 2 HORN BUTTON
- **ACCELERATOR PEDAL** COMBINED SWITCH

987954997

STEEL WHEEL

USB CONNECTOR

STEEL COLUMN ADJUSTER

FORWARD-BACKWARD LEVER

PARK BRAKE LEVER KEY SWITCH

SIDE SHIFT LEVER

TILT LEVER

AUXILIARY FUNCTION LEVER


COMBINED DISPLAY

1 1 1 1

- BRAKE PEDAL
- INCHING PEDAL

Figure 3. Controls and Switches (Sheet 2 of 2)

. Key



O (OFF)

removed This is the position at which the key may be inserted or

turned to this position. Gasoline and diesel engines will stop when the key is

| | | |

After the engine starts, the key remains in this position. The electric circuit is closed with the key in the **ON** position.

STAR

matically after starting. motor is engaged. Switch returns to the ON position auto-When the key is turned to the **START** position, the starter

Diesel Engines

come on momentarily. After the indicator light goes out, turn the key to the **START** position. Turn the key to the **ON** position. The indicator light will




CAUTION

- engine of off. Doing so will discharge the battery. Do not leave the key in the ON position when the
- Do not turn the key to the START position when motor engine is running. Doing so may damage the starter
- between attempts to start than 5 seconds at a time. Wait about 2 minutes Do not keep the key in the START position for more



2. Parking Brake Lever



Always set parking brake before leaving the truck ton and push lever forward to release the parking brake. Pull lever backward to set the parking brake. Depress but-

Forward-Backward Lever

umn. tronic reversing and is set on the left of the steering col-The forward-reverse lever of the truck is installed with elec-

- F Forward
- N Neutral
- After Allocation Backward



tral position before starting the engine. Do not forget to place the forward-reverse in the neu-CAUTION

Steering Column Tilting Angle Adjustment

Adjust the angle to suit the driver and pull up the lever to pushing down the lever at the left side of steering column. individual operators. The steering column is unlocked by The tilting angle of the steering wheel is adjustable to suit

Steering Wheel

made left. The steer wheels are located at the rear of the truck. right. When the wheel is turned left, the truck will turn to the When the wheel is turned right, the truck will turn to the The steering wheel is operated in the conventional manner. These cause the rear of truck to swing out when a turn is

Operating Devices and Operating Methods

6. Side Shift Control Lever

Used for left shifting and right shifting of the side shift bracket.

- Push forward to move to the left.
- Pull backward to move to the right.

Side shifting speed depends on the tilting angle of the handle and accelerator control.

- 7. Tilt Lever
- Move lever backward to tile mast backward.
- Move lever forward to tilt mast forward

Control tilt speed with tilt lever and accelerator pedal.



The tilt lock mechanism in the hydraulic control valve will not allow the mast to tilt forward while the engine is being shut down, even if the tilt lever is pushed forward.

8. Lift Lever

For lifting or lowering the forks.

- Lift forks by pulling lever backward
- Lower forks by pushing lever forward.

Control lifting/lowering speed with accelerator pedal.

- 9. Auxiliary Function Lever
- 10. Signal Light Lever

Use this lever which is at the right side of the steering column to indicate the turning direction of the truck.

- R Right Turn
- N Neutral
- L Left Turn

The turn signal lever does not automatically return to the neutral position unlike general passenger cars. It must be returned to the neutral position manually.

11. Horn Button

Press the rubber button at the center of the steering wheel to sound horn.

12. Light Switch

This light switch can be pulled out at two stops.

Operating Devices and Operating Methods



Stage	Power	Small	Head	Side
		Lamp	Lamp	Lamp
0	×			
1	×	×		×
2	×		X	×
(X) Means Connected	Connected			

- 13. Accelerator Peda
- Depress the accelerator pedal to increase speed.
- Release the accelerator pedal to decrease speed

WARNING

again, restart the engine without delay. comes to a stall. To put the power steering in operation hand-wheel operation is caused when the engine This truck is provided with power steering, so heavy

- 14. Dual Fuel Toggle Switch
- a. From LPG to Gas:
- switch from LPG position to GAS position to begin running on GAS. Start truck. (1) With the truck off, change the dual fuel toggle

- switch is set to GAS position and restart the engine. **(2)** If the engine stops, check that the dual fuel toggle
- b. From Gas to LPG:
- from **GAS** to **LPG** to run on **LPG**. Start truck. (1) With the truck off, place the dual fuel toggle switch
- gle switch is in **LPG** position and restart the engine. end of the vent cylinder. Check that the dual fuel tog-(2) If the engine stops, check the shutoff valve at the



CAUTION

weeks to avoid gasoline deterioration. Use gasoline to drive several miles at lease every two

either tuel. operating in cold environments. Once the engine has reached operating temperature, it can be run using It is recommended to start the engine using GAS when

When using LPG, you should pay attention to the following points:

Before driving, check cylinder and pipe for leakage. threads. Use a sealant on al LPG connections having NPT



- After LPG is working, before shutting down the engine
- cylinder shutoff valve and check if the engine leaks Before storing for a long time, completely close the
- If there is a leakage, fault, or other abnormal condivalve and have LPG system serviced. tion during moving, completely shut off the shutoff

15. Brake Peda

- Depress the pedal partially to slow vehicle.
- Depress the pedal fully to bring the vehicle to a stop.
- Release the pedal to resume vehicle operation.



CAUTION

over or falling cargo, causing accidents Avoid sudden braking which can lead to vehicle roll-

Inching Pedal

depressed fully, forklift will slow to a stop. and when slow speed is required. When a pedal is sure. Use inching pedal for Forklift loading and unloading Depress the pedal partially to decrease hydraulic oil pres-

CAUTION

slip. transmission oil temperature to rise and the clutch to Do not use the inching pedal too much, as it will cause

Load Backrest

goods. DO NOT use forklift truck without the load backrest. The load backrest improves stabilization when loading



Seat Adjustment




Figure 4. Seat and Seat Adjusting Lever

Adjust operator's seat to desired position, ensuring it provides easy access to all hand and foot controls. Unlock

seat by moving the adjusting lever to the right. Before operating truck, make sure that seat is securely locked.

WARNING

- Place key in OFF position before adjusting the seat.
- DO NOT attempt to adjust the seat while truck is moving.

Operator Presence System

WARNING

Always make sure the parking brake is fully applied before leaving the lift truck. If the operator leaves the lift truck without applying the parking brake, a seat activated switch will shift the transmission into neutral. If the truck is left on a grade, without the parking brake fully applied, the lift truck will free wheel down the grade, possibly causing injury or property damage.

These lift trucks are equipped with an Operator Presence System (OPS). The OPS feature has an electrical sensor in the seat which senses the presence of the operator. This allows the engine in internal combustion engines trucks to be engaged only when the operator is in the seat. The OPS is designed with a slight delay in the seat sensor to allow

then re-select a direction to re-engage the traction (travel mission (neutral position), the operator must select neutral transmission. When the seat sensor disengages the transthe operator to reposition himself without disengaging the

without applying the parking brake. transmission to neutral within 3 seconds when the operator A switch in the operator's seat will automatically shift the leaves the seat of the lift truck with the engine running and

Seat Belt

seat belt. Always fasten the seat belt operator resist side movement. It is not a substitute for the all possible injury in a tipover. The hip restraint will help the and the ground, but it cannot protect the operator against of the head and torso being trapped between the lift truck occurs. This restraint system is intended to reduce the risk confines of the truck frame and overhead guard if a tipover operator keep the head and torso substantially within the The seat belt provides an additional means to help the

figurations This lift truck is equipped with one of the two seat belt con-

Seat belt with no operation interlock.

Operating Devices and Operating Methods

Seat belt with operation interlock. Seat belt must be fastened for lift truck to start or to travel

Overhead Guard

guard. care when handling loads. Do not remove the overhead not be considered a substitute for good judgement and protect against every possible impact. Therefore, it must protection to the operator from falling objects, but cannot The OVERHEAD Guard is intended to offer reasonable

Hood

the front of hood until it latches. the aid of a hood damper. To lock the hood, push down on performing maintenance. The hood can be easily lifted with The hood can be fully opened to provide easy access when



CAUTION

pulled out Before opening the hood, the hood release should be



WARNING

engine must be off to avoid injury to hands or other While performing maintenance under the hood, the



body parts. The engine can be running in order to troubleshoot some problems. However, DO NOT place body under hood while engine is running.

Radiator Cap and Coolant Reservoir

The reservoir is located inside the hood.


The radiator is located under the radiator cover at the rear of the hood.

WARNING

- When the coolant temperature of the engine is higher than 70° C (158°F), DO NOT quickly open the pressure cap of the radiator. Loosen cap slowly to allow steam to escape. After that, tighten cap securely. It is good practice to use a thick waste cloth or the like when removing the cap.
- WEAR GLOVES when removing the radiator cap. You may get burnt on your hand if hot coolant splashes on it.
- Ethyl glycol antifreeze is harmful to a person. If swallowed, seek medical advice immediately.
- Keep antifreeze away from children.

Fork Position Lock

Used when adjusting the spacing of the forks. Pull the fork positioning pin and rotate 90°. Adjust the fork to the position desired for the material that is to be loaded. Rotate 90° the other way until the pin engages.





WARNING

- The forks should be set symmetrically to machine centerline, and fork stoppers should always be set.
- The lower beams of the carriage have a cut out section to load or unload forks.

Hydraulic Fluid Reservoir Cap

The hydraulic fluid reservoir cap is located on the right side of the hood. Fill hydraulic fluid through this filler port. The cap is provided with a dipstick. After filling hydraulic fluid, lock the cap.

Brake Fluid Reservoir

The brake fluid reservoir is provided at the left of the cab.



Operating Instructions

NOTE: Some notices for correct driving operation are introduced here, in order for your truck to maintain good performance, safe use, and frequent operation.

Use of New Truck

The service life of your truck depends on use at the time when the truck is new. In the early stage of 200-h operation, please pay high attention to the following items:

- Follow Periodic Maintenance Schedule.
- Avoid harsh operation, and avoid unreasonable use.
- Add lubricating oil and lubricating grease. Follow Periodic Maintenance Schedule.


Relationship between Load and Forklift Truck Stability


Within the load curve, the forklift truck takes the center of front wheel as pivot point, to maintain the mutual balance for the load on truck body and fork. Pay attention to the load amount and the load center, to maintain the truck stability.

WARNING

If it goes beyond the load curve, danger exists for the rear wheel to be raised and under this situation, as the forklift truck may possibly turn over, leading to severe accident. As indicated in the figure, the same result exists with cargo closed to fork tip and increase in cargo weight, while under such circumstances, the loading capacity shall be reduced along with.







BO990106

Load Center and Load Curve

Load center is the distance from the front end face of fork to the cargo center of gravity. The above mentioned load curve diagram has indicated the relationship between the truck load center and the allowable load quantity (load allowable for use). The data plate is attached on the truck, and it shall be replaced with a new one, if damaged or lost.



WARNING

If the truck is equipped with attachments, such as side moving device, bucket, or rotating fork, its load allowable for use that is lower than the corresponding standard trucks (without any attachment) is attributed to the following reasons:

- Load for weight of equivalent attachments is reduced.
 The load allowable for use is reduced in the s
- The load allowable for use is reduced in the same principle, as the length of attachments has moved the load center to move forward.
- The installation of attachments has moved the load center to move forward, called "Loss of Load Center".




 Avoid exceeding the load allowable according to the load curve pasted on truck or attachments.

Stability and Center of Gravity

The center of gravity (CG) of any object is the single point about which the object is balanced in all directions.

Every object has a CG. When the lift truck picks up a load, the truck and load have a new combined CG.



A. CG LOAD


B. CG TRUCK

C. COMBINED CG

The stability of the lift truck is determined by the location of its CG, or if the truck is loaded, the combined CG.

The lift truck has moving parts and therefore has a CG that moves. The CG moves forward and back as the mast is til-

ted forward and back. The CG moves up and down as the mast moves up and down.




The center of gravity, and therefore the stability of the loaded lift truck, is affected by a number of factors such as size, weight, shape, and position of the load; the height to which the load is raised; the amount of forward and backward tilt; tyre pressure and the dynamic forces created when the truck is moving. These dynamic forces are caused by things like acceleration, braking, turning, and operating on uneven surfaces or on an incline. These factors must be considered when traveling with an unloaded



truck, as well, because **an unloaded truck will tip over to the side easier** than a loaded truck with its load in the lowered position.

In order for the lift truck to be stable (not tip over forward or to the side), the CG must stay within the area of the lift truck represented by a triangle drawn between the drive axle and the pivot of the steering axle.




A. DRIVE AXLE B. STEERING AXLE C. TRUCK WILL TIP OVER


If the CG moves forward of the drive axle, the lift truck will tip forward. If the CG moves outside of the line represented by the lines drawn between the drive wheels and the steering axle pivot, the lift truck will tip to that side.

Capacity (Weight and Load Center)

The capacity of the lift truck is shown on the Nameplate. The capacity is listed in terms of weight and load center. The weight is specified in kilograms and pounds. The load center is specified in millimeters and inches. The capacity is the maximum load that the lift truck can handle, with the mast vertical, for the load condition shown on the Nameplate.







The load center of a load is determined by the location of its center of gravity. The load center is measured from the front face of the forks, or the load face of an attachment, to the center of gravity of the load. Both the vertical and horizontal load centers are specified on the Nameplate.

Loads should be transported while centered on the center-line of the lift truck. The operator must know whether or not a load is within the maximum capacity of the lift truck before the load is handled.

Transporting and Loading-Unloading of Forklift Truck

1. Transporting Forklift Truck

When cargo truck is used for transporting, apply the parking brake, use wheel chocks properly, and tie down straps rated for the weight of the lift truck. This will ensure the lift truck does not shift or move while in transport.

- 2. Loading-Unloading of Forklift Truck
- Use ramps typical of enough length, width, and strength.
- The parking brake of the cargo truck should be set and wheels chocked.
- The ramps should be placed at the width of the lift truck. Ensure the ramp surface is free of foreign materials.
- The ramps should be the same to ensure a stable operation of vehicle when forklift truck is loaded-unloaded.
- Do not change direction or perform any traverse movement on the ramps.



- 3. Lifting of Forklift Truck
- Forklift truck shall be lifted by personnel who have been specially trained.
- The properly weight rated lifting straps should be used to hook up the designated lifting position on forklift truck.
- Designated lifting positions are also available for the detachable parts and components on forklift truck.

Inspection Before Operation

Report damage or faulty operation immediately. Do not operate a lift truck that needs repair. A lift truck will only do its job when it is in proper working order. If repairs are required, install a tag in the operator's area stating "DO NOT OPERATE" and remove the key from the key switch if truck is equipped with key switch option.

Checks With the Engine Stopped

Before using the lift truck, make the following checks:

- Condition of forks, carriage, chains, header hoses, mast, attachment, and overhead guard.
- Condition of wheels and tires.

- Seat belt fastens correctly.
- Seat is correctly fastened to its mounts. Hood is correctly latched.
- Condition of the engine compartment. Ensure all surfaces are free of oils, lubricants, fuel, and organic dusts or fibers (paper, wood, cotton, agricultural grass/grain, etc).
 Remove all foreign materials.
- Coolant level in the cooling system and condition of the drive belts.
- Condition of the radiator and screen. Clean if necessary.
- Fuel level
- Oil level in the engine.
- Oil level in the hydraulic tank
- Leaks from the engine, transmission, hydraulic system, and fuel system.
- Loose or missing hardware.
- Check transmission oil level.

Place feet carefully. Always face the lift truck when climbing on or off. Use added care when surfaces are slippery.



Keep hands free of any obstacles such as food, beverages or tools.

Mounting and Dismounting

WARNING


To avoid serious injury when entering or exiting the lift truck, ALWAYS USE 3 POINTS OF CONTACT. Maintain contact simultaneously with two hands and one foot or with two feet and one hand while climbing on or off the lift truck.

Place feet carefully. Always face the lift truck when climbing on or off. Use added care when surfaces are slippery. Keep hands free of any obstacles such as food, beverages, or tools.

Safety Step and Safety Grip

Safety steps are provided on both sides of the truck body.

The safety grip is located on the front left pillar of the overhead guard. Use both the safety step and safety grip when mounting and dismounting the truck.





Starting Procedure

ments, from any place other than the desincluding any of its functions or attach-DO NOT start or operate the lift truck ignated operator's position.



BO190112

WARNING

repaired and the atmosphere is free of LPG tem. DO NOT start the engine until the fuel leak is fuel can indicate a leak in the fuel sys-LPG is very flammable. An odor of LPG

out of the intake manifold and cylinders. 80% during cranking, the ECU will not allow any fuel into the engine. This allows the engine to clear any excess fuel into the ECU. When accelerator is depressed more than **NOTE:** Lift trucks have a "Clear Flood Mode" programmed

- If the lift truck uses LPG fuel, open fuel valve on LPG
- Make sure that parking brake is applied
- position 3. Put direction control lever for transmission in NEUTRAL
- Make sure lift truck hood is closed.

- light will illuminate and the cold start circuit will be enera diesel engine and engine is cold, the cold start indicator Turn key to the ON position. If lift truck is equipped with
- 6. On lift trucks equipped with a LPG engine, turn the key to the START position to engage the starter

delay is required, the cold start indicator will be illuminated to engage the starter. countdown reaches 0, turn the key to the START position and a countdown time of ten seconds is displayed. When On lift trucks equipped with a diesel engine, if cold start



WARNING

FASTEN SEAT BELT IF LIFT TRUCK TIPS OVER:

- DO NOT Jump Stay On Truck
- Hold Firmly To Steering Wheel Brace Feet Lean Forward And Away From Impact

IF IT IS FASTENED. the truck if the lift truck tips over. IT CAN ONLY HELP The seat belt is installed to help the operator stay on



The operator must be aware that the lift truck can tip over. There is a great risk that the operator or someone else can be killed or injured if trapped or hit by the truck as it tips over. The risk of injury can be reduced if the operator stays on the truck. If the truck tips over, do not jump off!

Operating Techniques



Before operating the lift truck, FASTEN YOUR SEAT BELT.



There are a number of operations, if not performed carefully, that can cause the lift truck to tip. If you have not read the WARNING page in the front of this Operating Manual, do so NOW. As you study the following information about how to properly operate a lift truck, remember the WARNINGS.

NOTE: When the Emergency Locking Retractor (ELR) seat belt is properly buckled across the operator, the belt will permit slight operator repositioning without activating the locking mechanism. If the truck tips, travels off a dock, or comes to a sudden stop, the locking mechanism will be activated and hold the operator's lower torso in the seat.

Lift Truck Interlocks

Certain operator actions, if not performed correctly while operating the lift truck, will cause traction and the hydraulic functions to become disabled.

ator is in the seat (occupancy sensor), seat belt should be fastened, a direction of travel is selected, engine is running, and the parking brake is released. If any of the above actions are not performed while operating the lift truck, traction will be disabled. To reactivate traction, the operator must return to the seat. Once the needed actions are completed, traction will be enabled and the operator can continue to load and unload material.

enabled when the operator is in the seat (occupancy sensor), seat belt should be fastened, and the engine is running. If any of the above actions are not performed while operating the lift truck, the hydraulic functions will be disabled. The LCD screen on the display panel will provide an icon. Seat Belt Indicator light will be on. To reactivate hydraulics, the operator must return to the seat and fasten seat belt. Once the needed actions are completed, the



hydraulic function will be enabled and the operator can continue to load and unload material.

Starting Forklift Truck

1. Before Starting Forklift Truck

Prior to truck operation, the lift truck should be inspected as to whether or not all the control devices and warning devices are under normal operation. If there is any damage or failure which has not yet been corrected, the lift truck should not be operated.

NOTE: It is not necessary to "pump" the accel pedal, or to hold to the floor before starting. This may cause a failure to start.

Inspect the safety conditions around the truck.

- Check the surroundings around the vehicle.
- Ensure that the gear shift lever and multi-way valve handle are placed in **NEUTRAL** and the parking brake lever is fully engaged.
- a. Start Gasoline/LPG Engine
- Cooling

Depress the accelerator pedal 2-3 times. Return the preheating start switch to **START** position and start the engine. Release the switch key after starting the engine.

b. Heat engine

Depress ½ way and hold the accelerator pedal. Return the preheating start switch to **START** position and start the engine. Release the switch key after starting the engine.

c. Start Diesel Engine

Turn the preheating start switch to **ON** position until the preheating indicator goes off. Turn the preheating start switch to **START** position. If it is hard to start the engine, check whether the fuel level is too low, the condition of air mixing in fuel system or whether preheating wire is broken.

- 2. After Starting Engine
- Preheating the engine (about 5 minutes)
- Check the engine rotation (sounds or gears)

After the engine is preheated completely, completely operate the handle of multiple unit valve for 2-3 times to check its working condition.

Operating Instructions




- Check the sounds of fire (or misfire).
- Check air exhaust condition (density).
- Make sure that all indicator lights go off.

Running

Operator's Position

While sitting in the seat and wearing the safety belt, ensure your back and waist are as close to the seat back as possible.

Hold the handgrip of steering wheel using left hand, and the right hand is gently put up on the steering wheel and get ready for loading-unloading operation.




2. Basic Running Conditions

Ensure the bottom surface of the fork is off the ground by 15-20 cm (6-8 in.), and the mast tilts back in place.









Inspect surroundings for safety. Look around the forklift truck. Signal prior to start of truck.



an aid to the driver, but are NOT driving mirrors and side to observe their tail swing area. These mirrors are Some lift trucks have mirrors for viewing along the must NOT be used as such when operating in reverse.


> to something or injury to someone. Always look in the direction of travel to avoid damage








- a. Depress the brake pedal and operate forward backward gear shift knob,
- **b.** Release the parking brake handle.








c. Release the brake pedal and depress the accelerator pedal. The vehicle is operational.

Gear shift.

Releasing the brake enables the truck to start at a higher gear when unloaded, while it is necessary to start the vehicle at low gear under loading condition.



- 4. Hydraulic Transmission Forklift Truck
- a. Deceleration.
- (1) Come to a complete stop before changing the travel direction of the vehicle (Forward-Reverse).



WARNING

The truck must be decelerated (Slowed):

- At crossroads.
- In crowded places pedestrian walkways).
- On rough grounds and other rugged surfaces.
- Approaching cargo or obstacle.



WARNING

Parking

- Truck to be parked on a level ground It is the best the slope, and stop the wheels using wedge blocks, to prevent accidental downslide. be parked on a slope, park the truck horizontally on to park the truck in a spacious place, and if it has to
- place where traffic is not hindered, and labels or sig-Truck shall be parked in a designated area or a nal lights may be set around the truck, if required.
- and it is to be avoided to park the truck on a loose and soft muddy land or a rather slippery pavement Truck shall be parked on a firm and hard ground,

where traffic is not hindered. the end of the fork, and park the truck in a place fork fails to drop on ground, hang a warning flag on In the case when lifting system is damaged, and the

not hindered, and: NOTE: Parking: Park the truck in the place where traffic is

- Pull up the handle for parking brake
- Drop the fork to ground
- Turn the key switch to **OFF** position, and press the emergency power disconnecting switch.
- Remove the key and keep it properly.
- 5. Hydraulic Transmission Forklift Truck

pedal if necessary. Lift foot from the accelerator pedal, and depress the brake

a. Steering.

the truck is to turn (right/Left). The steering wheel will (decelerate) the truck, and steer the direction in which rear to rotate outwards during steering. Slow down forklift trucks are mounted in the rear, which allows the Different from normal vehicles, the steering wheels of



rotate somewhat beforehand compared with the truck of front-wheel turning.

b. Stopped or parking.

Decelerate, depress the brake pedal for truck to stop, and place the in **NEUTRAL (N)**. Apply parking brake.

c. Towing Truck for Service

NOTE: If failure occurs with forklift truck during operation, the truck will be towed away for repair, to avoid hindering the operation of other vehicles and personnel.

Loading

- The spacing of fork should be spread as far as possible stability.
- The forklift truck and the cargo should be aligned, when forks insert into pallet or directly into cargo.
- 3. The forks must be inserted into the pallet evenly.
- 4. Ensure the forks are fully inserted.
- Cargo Lifting:
- a. Lift cargo off ground by 5-10 cm (2-4 in.), and ensure cargo is stable and secure.

- **b.** Tilt the mast backward. Lift the cargo off the ground by 15-20 cm (6-8 in.), and then begin transporting.
- (1) Large cargo should be transported in reverse except when climbing a slope.
- (2) DO NOT transport cargo by forks alone
- (3) DO NOT drag cargo with forks

Stacking

NOTE: Inspect the following before operation of forklift truck:

- Ensure that there is no loose or damaged cargo in stacking area.
- Ensure that there are no objects or cargo stacks that may hinder safety in the stacking area.

Stacking should be performed according to the Following procedure:1. Operate truck at a decelerated speed when the stacking

- Operate truck at a decelerated speed when the stacking area is approached.
- 2. Park the truck in front of the stacking area.
- 3. Ensure it is safe around the stacking area.

Operating Instructions



- **4.** Adjust the position of forklift truck as needed. Place forklift truck in position where the cargo is to be placed in the stacking area.
- **5.** Ensure the mast is vertical to the ground, and the forks exceed the height of stacked cargo.
- **6.** Inspect the stacking position and slowly move forward to park the truck at a proper stacking position.
- 7. Ensure that cargo is above the cargo stacking position. Slowly lower the forks, and ensure that cargo has been properly placed.
- 8. When cargo is not completely placed/stacked on rack or bearer:
- a. Lower the cargo until the forks no longer bear the weight.
- **b.** Run the forklift truck backwards by 1/4 length of the forks.
- **c.** Lift the forks by 5-10 cm (2-4 in.). Move the truck forward and place the cargo in a proper stacking position.
- **9.** When cargo is stacked, inspect the operating area behind the forklift truck. If area is safe, run the truck backward to avoid bumping forks and pallet into each other.

10. Ensure that the front part of forks has left the cargo or pallet, and lower the forks to proper operating height.

Unloading

Unloading should be performed using the following procedures:

- Ensure to operate at a decelerated speed when the truck approaches the cargo to be transported.
- **2.** Park the truck in front of the cargo (30 cm (12 in.) distance between cargo and fork tip).
- 3. Adjust the position of forklift truck in front of the cargo.
- 4. Ensure that cargo will not overload the truck.
- **5.** Ensure the mast is vertical to the ground.
- **6.** Ensure the fork position is placed where the cargo is stable. Move the forklift truck forward, until the fork is completely inserted into pallet.
- 7. When forks will not completely insert into pallet:
- a. Insert 3/4 of the forks and raise one side of the pallet5-10 cm (2-4 in.).



- **b.** When possible, insert the forks completely into the pallet.
- **8.** After forks are inserted into pallet, raise the pallet 5-10 cm (2-4 in.).
- **9.** Ensure the operating area is clear and move the forklift truck until the cargo can be lowered to operating height.
- 10. Lower the cargo off ground by 15-20 cm (6-8 in.).
- 11. Tilt mast backwards to ensure the stability of cargo.
- **12.** Transport the cargo to the destination.

Storage



When the truck is in need of repairs for operational or safety issues, this should be reported immediately. The truck should be removed from daily operations until repairs are completed.

1. Before Storage:

The forklift truck should be thoroughly cleaned and inspected according to the following procedure:

- **a.** Remove the oil and grease attached on the truck body using a cloth and clear water, as per requirement.
- **b.** When truck body is cleaned, inspect the overall condition of the truck. It is especially required to inspect whether or not the vehicle body is damaged, whether or not tires are worn or embedded with foreign objects.
- c. Fill the oil tank with the specified oil.
- **d.** Inspect for oil leaks.
- e. Add lubricating grease as per requirement
- f. Inspect for loose wheel nuts and wear on cylinder rods.
- **g.** Inspect the rotation for roller of mast is smooth.
- Lift the mast cylinders to highest point and fill cylinder up with oil.
- i. In the winter or cold season, the long-acting antifreeze does not need to be released if filled with water. Drain before storage.

Operating Instructions



2. Routine Storage

The following service and inspections should be performed after Routine Storage is completed.

- a. Park the forklift truck in the designated place using wedge blocks for wheels.
- **b.** Place the gear-shift handle to the **NEUTRAL** position, and pull up the parking brake handle.
- c. Turn the key switch to OFF position, operate the control rod for multi-way valve for a number of times, and release the remaining pressure in the cylinder and the hydraulic liner.
- **d.** Remove the key and have it placed and kept in a safe place.
- 3. Long Term Storage

The following service and inspections should be performed after Routine Storage is completed.

a. Park the truck high ground in consideration of the rainy season.

- b. Remove the battery from the forklift truck. Whether the forklift truck is parked outdoors or indoors, the battery should be placed in a dry, shady, and cool place. If the battery is placed is wet and hot area, ensure to charge once every month.
- **c.** Coat the exposed parts such as cylinder piston rods and the shafts that may possibly be rusted, with antirust oil.
- **d.** Cover the parts and components liable to be affected with inclimate weather.
- **e.** The truck should be operated at least once a week. The oil and grease on piston rods and shafts should be removed. The power supply should be turned **ON** to allow the truck to operate forward and backward. The hydraulic control should be operated for a number of times.
- **f.** Avoid parking the forklift truck on loose and soft pavements in summer.



- 4. Operation of Forklift Truck after Long Term Storage:
- a. Remove the antirust oil from the exposed parts.
- **b.** Remove the foreign substances and water in hydraulic oil tank.
- **c.** Charge the battery, mount it on the forklift truck, and connect with the lead wire of battery.
- **d.** Add coolant to the required level.
- e. Carefully inspect everything before starting.
- f. Preheat forklift.



Periodic Maintenance

A daily inspection of the forklift truck may avoid truck failure and inability to reach its due service life. The number of hours listed in this section and Regular Maintenance Timetable, based on 8-hour work a day and 200-hours a month.

Detailed records should be kept after inspection, and the records should be retained for 3 years.

- Only trained, qualified personnel can maintain and repair forklift truck.
- Daily and monthly inspections and maintenance may be accomplished by operators.

Periodic Maintenance Requirements

- 1. Ensure only authentic parts and components are used.
- 2. Ensure only authentic or designated oils and greases are used.
- **3.** Clean up the oil filler port and grease nipple using brush or cleaning cloth prior to oil or grease addition.
- **4.** The truck should be parked on a level ground for inspection of oil level and oil addition.

- Preventive Maintenance and service should be regularly performed, and attention should be paid not to injure yourself.
- **6.** When inspecting or repairing suspended forks or attachments, the proper support brace should be used to support the forks or the attachment, to prevent downslide of fork and inner mast.
- 7. It should be reported to the managerial personnel if any damage or failure is found. It is prohibited to use this forklift truck before it is repaired.

Periodic Maintenance Items

- Inspection for Leakage of Hydraulic Oil and Transmission Case Oil
- **a.** Inspect whether or not oil leaks exist within the joints of hydraulic drive system.
- b. Check whether there are impurities in the fuel

WARNING

If a fuel leak is discovered before operations, do not start the truck. Repair before operation.



- Inspect Tire Air Pressure (Pneumatic Tire)
- ditions tires or damage to tire may cause different steering conity consumption. Different air pressures for left and right may reduce the service life of tire, and increase electrica. Inspect the condition of the tires. Low air pressure
- sures forklift truck has indicated the tire standard air presb. The data plate attached on the side of the hood of the

GDP20-25UX GDP	Capacity	GLP/	GLP/
860	Tire Pressure	GDP20-25UX	GDP30-35UX
080	Front Tire/KPa	860	970
000	Rear Tire/KPa	860	700

- gauge to measure air pressure of tire. Adjust the presc. Screw off valve cap counterclockwise, and use a tire cap after it is confirmed that there is no air leakage sure to specified value if required, and screw on the lid
- d. Inspect whether or not damage exists with the surface/sidewall of tire. Also, inspect the rim for damage.

e. The proper tire air pressure is required in order for air pressure variation may cause an accident. trucks to transport heavy loads. Any damage to rim or



WARNING

- pressure tires. Tire pressure must not exceed the specified torques. This must occur before air is added to the bolts and nuts shall be tightened to the specified After tires and rims have been assembled, all the
- When an air compressor is used, the pressure should be properly adjusted. As the maximum outmay cause severe accident if it is improperly adjusput of pressure for an air compressor is very high, it
- Inspection of Wheel Hub Nut Torque
- a. Inspect whether or not the hub nut torque is correct.
- 470-550 N·m (346-405 lbf ft). b. All the wheel hub nuts shall be tightened to
- When wheel hub nut is removed, never remove a separate wheel hub nut by mistake.




- It is very dangerous for wheel hub nut to be torqued turnover of the truck. improperly. In case, the wheel may come off, leading to
- Inspection of Overhead Guard

structural components are secure and not damaged should be ensured that it is firmly mounted and all the The overhead guard plays a protective function, and it

Inspection of Brake Fluid Level

water do not enter into the fluid reservoir during addition. should be between the two scale marks. Ensure dust or Inspect the level of brake fluid reservoir. The fluid level

6. Inspection of Battery Electrolyte



Inspection for Quantity of Battery Electrolyte

2 lines the battery. The liquid level should be located between the There are scale lines for upper and lower liquid levels on



WARNING

generate hydrogen and cause explosion. Open fire around the fluid filling hole of battery may




8. Coolant Level Inspection

WARNING

DO NOT remove the radiator cap from the radiator when the engine is hot. When the radiator cap is removed, the pressure is released from the system. If the system is hot, the steam and boiling coolant can cause burns. DO NOT remove the cover for the radiator when the engine is running.

Inspect the liquid level of the coolant tank. The liquid level should be between the lower and upper scale marks. Add coolant if necessary.



9. Engine Oil Level Inspection

Engine oil level gauge is located on the left side of the engine. Remove the oil level gauge and insert it again after



cleaning to check whether the oil level is located between two scale lines.

10. Fan Belt Tension Level Inspection

Inspect the tension of the fan belt and whether it is damaged by pressing the middle part of the belt between the water pump and generator.

WARNING

The engine must be turned OFF when checking the tension of the fan belt.

Inspection of Rear Combination Light

Inspect whether or not damage exists with the rear combination light (tail light, parking light, and reverse light).

12. Level of Hydraulic Oil Inspection

Inspect the hydraulic oil level using the dipstick. Remove the dipstick and wipe it off. Re-insert it and then pull it out to see whether or not the oil level is located between the high and low two scale lines.


NOTE: Power supply shall be turned **OFF**. The forks should be dropped to the ground and the forklift truck

should be parked on a level surface when oil level is inspected.

Pipeline of Cylinder Inspection

Visually inspect whether or not oil leaks exists with hydraulic lifting and tilting cylinders.

14. Power Shift Gearbox Oil Level Inspection





Hydraulic Transmission Forklift Truck


Open the inspection cap and remove the filler cap. Check the oil level gauge to ensure that the oil level is at the proper level. If necessary, add proper hydraulic oil.

Inspection of Backrest

Inspect whether or not the mounted bolts for backrest are secure. They should be tightened when required.

2. Fork and Fork Positioning Pin Inspection

Inspect the mounting condition of positioning pin and whether or not the forks are distorted or cracked.



Front Headlight and Front Combination Light Inspection Inspect whether or not the lamp screens are clean or damaged.

4. Seat Adjustment

Ensure that the seat is at a proper position. To adjust, pull the adjusting handle rightward. Ensure the seat position



where it is easy for foot and hand operations. After adjustment, ensure that it is reliably locked up.

5. Inspection of Reverse Handle

Inspect whether or not reversing handle is operational.

6. Inspection of Multi-way Valve Operating Handle

Inspect whether or not operating handles (Lifting, Tilting, and Attachments) are operational.

7. Inspection for Operation of Parking Brake

Ensure that the parking brake is safe and reliable, after the parking brake handle is activated.

Preparation prior to Start

Before turning **ON** the power supply, ensure that the gearshift handle is located in **NEUTRAL**, and parking brake is activated.

8. Instruments

Hourmeter, trouble meter and running speedometer enable operators to understand the condition of truck during operation.

9. Inspection of fuel volume

The fuel gauge is installed on the instrument panel. Check whether the fuel volume can satisfy the requirements of a day's working use.

10. Lamplights

Turn on the light switch, and confirm that corresponding lights are all under normal conditions.

11. Inspection of Turn Signal

Operate the turn signal handle to ensure the normal work of turn signal.

12. Inspection for Operation of Horn Pushbutton

Press the horn pushbutton to ensure whether or not the horn sounds.

Mechanical Transmission Forklift Truck

1. Idle Stroke of Brake Pedal Inspection

Press the brake pedal and inching pedal (only applies to hydraulic transmission forklift truck) to ensure the actions of all pedals are operational and the pedals can reset without interference.



2. Mast Operation Inspection

Press the horn and operate the lifting and tilting handle to ensure the lifting and lowering of the fork arm is normal and the tilting of the mast is stable. Ensure the cylinder piston can operate to the end of travel. The working condition and sound of overflow valve is normal. Pay attention to the sound of system operation.

3. Inspection of Tensioning Degree for Lifting Chain

Inspect the tensioning condition of lifting chain and whether or not damage exists.

When tensioning condition is inspected, the forks should be lifted by about 5 cm (2 in.) and the middle part of the chain is pushed and pressed by using thumb. Ensure whether or not the tensioning conditions of left and right chains are consistent, while the locking nut (A) for the fixed pin is loosened and the adjusting nut (B) is screwed and adjusted to adjust the chains.

NOTE: Use mechanical oil (such as hydraulic oil) for lubrication of lifting chains, and avoid using lubricating grease.

Steering Wheel Free Stroke Inspection

Inspect the rotation as well as the axial loosening condition of steering wheel. The normal free stroke is 50-100 mm (2-4 in.), and axial loosening is not allowed.

Inspection of Air Exhaust

Inspect the air exhaust condition after the engine has reached operating temperature..

Inspect whether there are abnormal sounds or variations in engine and driving system.

White above	Black abı	No color or light blue norr
abnormal: burn oil	abnormal: incomplete combustion	normal: complete combustion

NOTE: Because the engine exhaust air is harmful and may cause danger of poisoning when starting in a closed space. Ensure there is sufficient oxygen. Regularly inspect the volume of exhaust air emission. Inspection of air exhaust should be vented outdoors and be careful to avoid fire. Be careful of the leakage of oil or other fuel materials. Do not leave waste cloth or paper on the engine body and place the fire-extinguishing equipment in proper position.



Running at low speed – (in a safe place)

Ensure to recheck the volume of exhaust air and comply with the requirements of specified government rules and regulations after the engine is repaired or adjusted.

- 6. Inspection of Inching Pedal
- **a.** Slightly press the inching pedal to check the deceleration condition of the vehicle.
- 7. Inspection of Brake

Operate the truck at a slow speed and depress the brake pedal to examine the braking effect. The brake light turns on after the brake pedal is pushed down.

8. Inspection of Steering

Turn the steering wheel when truck is running at a slow speed and observe whether or not the left and right steering forces are consistent, and whether or not other abnormal effects exist.

Inspection of Parking Brake

WARNING

If the park brake switches are not adjusted correctly, the engine can be started with the park brake released.

The purpose of the left-hand mounted switch is to prevent the started motor from being energized when the parking brake is not applied. The right-hand mounted switch de-energizes the forward/reverse solenoids to put the transmission in neutral when the park brake is set.

Check the operation of the parking brake. The operator must adjust the parking brake so the lift truck does not move if parked on an incline. The parking brake, when in good condition and correctly adjusted, will hold a lift truck with a capacity load on a 15% grade, a slope that increases 1.5 m in 10 m (1.5 ft in 10 ft).

Turn the adjustment knob at the bottom of the lever to adjust the parking brake. Do not tighten the adjustment so that the brake is applied when the lever is released. The lever for the parking brake has a lock. Use your thumb or finger to release the lock on the lever when the parking brake is locked.

Inspection of Reverse Light and Reverse Buzzer

The reverse light turns on and the reverse buzzer sounds when direction control handle is placed in **REVERSE** gear.



Periodic Maintenance

- 1. When the Indicator of Oil-Water Separator Lights up:
- **a.** Turn **OFF** the engine, rotate (A) section for 4 to 5 circles to loosen water drainage screw plug. Keep pressing pump (B) until water completely flows out of the oil-water separator.
- b. Tighten the water drainage screw plug and press the pump (B) for several times to check whether the screw plug has leakage.
- **c.** Ensure the indicator light goes off after starting the engine.
- 2. Air Exhaust of Fuel System
- a. Turn OFF the engine and loosen the exhaust plug (C) on injection pump. Press the pump to exhaust air until the fuel flows out of the screw plug.
- **b.** Tighten the exhaust plug to ensure that no fuel leaks
- 3. Replacement of Fuse

Fuses are able to protect electrical systems and to prevent over-high current. If it occurs that some part fails to work,

possibly the corresponding fuse is already burned out. It must be replaced with a fuse wire of the same capacity.

- 4. Replacement or Repair of Tire
- a. Front Wheel
- (1) Park the truck on a firm and hard pavement and turn OFF the engine.
- (2) Pull up the parking brake handle and block wheels using a wedge block. Place the jack under the truck body.
- (3) Jack up the truck and keep the tire on the ground. Loosen the nuts for wheel hub, but don't remove the tire.
- (4) Continue jacking up the truck until the tire is off the ground. Take off the nuts and remove the tire.
- (5) The installation of the tire is opposite to the disassembly sequence. The wheel hub nuts should be tightened up in a diagonal order.

Inspect the tire air pressure after it has been assembled



b. Rear Wheel

The procedure is the same as the repair and replacement methods for the front wheel, except that the jack should be placed under the counter weight.

Forks

The identification of a fork describes how the fork is connected to the carriage. These lift trucks have hook forks.

Forks, Remove

WARNING

DO NOT try to move a fork without a lifting device. Each hook fork for these lift trucks can weigh 45 to 115 kg (99 to 253 lb).

NOTE: Forks are to be replaced only in sets and not individually.

NOTE: If lift truck is equipped with a fork positioner attachment, perform **Step 1** and **Step 2**. If lift truck is not equipped with a fork positioner attachment, go to **Step 2**.

- Lower carriage and remove four capscrews from inner fork carriers. Remove inner fork carriers from integral sideshift carriage. See Figure 5.
- 2. A fork can be removed from the carriage for replacement of the fork or other maintenance. Slide a hook fork to the fork removal notch on the carriage. See **Figure 6**.

Lower the fork onto blocks so that the bottom hook of the fork moves through the fork removal notch. See **Figure 6**

Lower the carriage further so that the top hook of the fork is disengaged from the top carriage bar. Move the carriage away from the fork, or use a lifting device to move the fork away from the carriage.




Figure 5. Carriage and Forks

FORK


Ņ

FORK REMOVAL NOTCH

ယ

INNDER SLIDE FRAME





- BLOCKS HOOK FORK

CARRIAGE BARS

Figure 6. Remove a Hook Fork

Forks, Inspect



forks or adding shims. Replace bent forks DO NOT try to correct for tip alignment by bending the

only in sets and not individually. dures. Replace damaged fork. Forks are to be replaced Forks are made of special steel using special proce-Never repair damaged forks by heating or welding.

bottom of the fork is not worn (Item 4 in Figure 7). fork tips are aligned as shown in **Figure 7** . Check that the Inspect the forks for cracks and wear. Check that the



CAUTION

attachment. Damage to forks and other carriage components can occur if fork latch pins are not removed Remove fork latch pins if adding a fork positioner

keep the forks locked in position. Replace any damaged or broken parts that are used to


prior to using attachment.

10% of original thickness. if fork wear is more than 10%, Inspect fork wear. Ensure heel wear is not more than



fork must be replaced or rerated. Perform fork wear inspection using a BOL256N1 caliper ruler as follows. See **Fig-ure 7**.

- a. Determine normal thickness of "N" of fork using scale or ruler portion of caliper ruler. Measurement has to be done on fork shank using caliper ruler.
- b. Position caliper at end of heel internal radius (item 4,
 Figure 7) with opening corresponding to measured
- thickness of fork shank in **Step a** above. (e.g. for N 1.75 use N 1.75 opening). This is typically the section of fork where wear is greatest. Note that opening distance has been reduced by 10% from nominal thickness.
- **c.** If fork enters opening, it is mandatory to replace it. DANGER OF BREAKING. Furthermore, a 10% reduction in fork blade thickness results in 20% reduction in operating capacity.



Fork Tip Alignment	Nignment
Length of Forks	3% Dimension
914 mm (36 in)	27 mm (1.08 in)
1016 mm (40 in)	30 mm (1.2 in)
1067 mm (42 in)	32 mm (1.26 in)
1207 mm (47.5 in)	36 mm (1.42 in)
1219 mm (48 in)	37 mm (1.46 in)
1372 mm (54 in)	41 mm (1.61 in)
1524 mm (60 in)	45 mm (1.81 in)
1829 mm (72 in)	55 mm (2.17 in)

- TIP ALIGNMENT (MUST BE WITHIN 3% OF FORK LENGTH)
 CRACKS
 LATCH DAMAGE
 HEEL OF FORK (MUST BE 90% OF DIMENSION "X")
- LOAD BACKREST EXTENSION MAXIMUM ANGLE 93° CARRIAGE
- FORK REMOVAL NOTCH

Figure 7. Forks Check

BO190157






Figure 8. Fork Wear

Forks, Install

- 1. Move the fork and carriage so that the top hook on the fork can engage the upper carriage bar. Raise the carriage to move the lower hook through the fork removal notch. Slide the fork on the carriage so that both upper and lower hooks engage the carriage. Engage the lock pin with a notch in the upper carriage bar.
- 2. If lift truck is equipped with a fork positioner attachment, install fork carriers using four capscrews. Tighten capscrews to 35 N•m (25 lbf ft).

Periodic Maintenance Tables

This timetable is set based on the standard working time and operating conditions. Perform the maintenance at regular intervals (C = Check, R = Replace). See **Table 2** through **Table 10**.



Table 2. Engine

0 =	0 =	Engine	m	(0	7.	ltem
Inspecting and adjusting valve clearance	Inspecting crankcase and cleaning scale	Cleaning or replacing air filter core	Exhaust color	Sound of engine	Visually inspecting engine run- ning condition	Inspection Item
Thick Feeler Gauge						Tool
			C	C	С	Daily (8 Hours)
		С	C	C	С	Monthly (200 Hours)
	С	С	C	C	С	Quarterly (600 Hours
С	С	Z)	C	C	С	Semi- annually (1200 Hours)
C	С	Z)	C	C	С	Annually (2400 Hours)



Table 2. Engine (Continued)

ltem	Inspection Item	Tool	Daily (8 Hours)	Monthly (200 Hours)	Quarterly (600 Hours	Semi- annually (1200 Hours)	Annually (2400 Hours)
		4		С			С
Engine (Con- tinued)	Torquing cylinder head bolt	Torque Wrench		Only first for gasoline engine			Only for C240 Die- sel Engine
	Inspecting cylinder compression pressure	Pressure Gauge					С
Crankshaft Ventilation Device	Inspecting the blocked or damaged condition of valve and pipe					С	С
Speed Gover- nor or Injec- tion Pump	Inspecting the maximum rotational speed at no load	Tachome- ter					n

Table 2. Engine (Continued)

	Lubrication System			ltem
Replacing engine oil filter core	Replacing engine oil	Inspecting oil volume and cleanliness	Whether or not oil leak with engine	Inspection Item
				Tool
		С	С	Daily (8 Hours)
R 50 Hours for First Time	R 50 Hours for First Time	С	С	Monthly (200 Hours)
ZJ	7J	С	С	Quarterly (600 Hours
ZJ	R	С	С	Semi- annually (1200 Hours)
ZJ	R	С	С	Annually (2400 Hours)



Table 2. Engine (Continued)

a fc	<u> </u>	Fuel System R	<u> </u>	fil⊓	<u>> د ت</u>	ltem Ir
Inspecting loosening condition for the connecting mechanism and cleanliness of carburetor	Inspecting nozzle, and adjusting pressure condition (diesel engine)	Replacing fuel filter (diesel engine)	Cleaning fuel filter (gasoline engine)	Inspecting whether or not fuel filter is blocked	Visually inspecting whether or not oil leak with oil pipe, oil pump, and oil tank	Inspection Item
	Inject test machine					Tool
					С	Daily (8 Hours)
					С	Monthly (200 Hours)
С		R	С	С	С	Quarterly (600 Hours
С	С	R	С	С	С	Semi- annually (1200 Hours)
C	С	7J	7J	С	С	Annually (2400 Hours)



Table 2. Engine (Continued)

Item	Inspection Item	ТооІ	Daily (8 Hours)	Monthly (200 Hours)	Quarterly (600 Hours	Semi- annually (1200 Hours)	Annually (2400 Hours)
	Ignition moment (diesel engine)	Time Meter			С	C	С
Fuel System	Jet moment (diesel engine)						С
(Continued)	Water discharge for fuel tank				0	С	0
	Cleaning fuel tank					С	С
	Inspecting fuel volume		С	С	С	С	С
	Coolant volume		С	С	0	С	С
	Leaking condition		С	С	С	С	С
	Rubber hose ageing condition				С	С	С
Cooling Sys- tem	Performance and installation condition of radiator cover			С	С	С	С
	Cleaning or replacing coolant				R	7J	R
	Inspecting tensioning force and damage condition for belt of fan		C	C	C	O	O



Table 3. Power Transmission

			Case	Hydraulic				Item
	Replacing oil suction filter core	Idle stroke and movement condition of inching pedal	Performance of inching valve	Performance of control valve and hydraulic clutch	Operating and loosening condition of gear-shift lever	Inspecting oil volume and replacing oil	Leaking condition	Inspecting Item
								Tool
		С	С	С			С	Daily (8 Hours)
200 Hours for First Time	ZJ	С	С	С	С	С	С	Monthly (200 Hours)
		С	С	С	С	С	С	Quarterly (600 Hours
	ZJ	С	С	С	С	R	С	Semi- annually (1200 Hours)
	IJ	С	С	С	С	R	С	Annually (2400 Hours)



Table 3. Power Transmission (Continued)

	Front Axle		ltem
Loosening condition of mount- Detection ing bolt Hammer	Replacing oil	Leaking inspecting	Inspecting Item
Detection Hammer			Tool
		С	Daily (8 Hours)
С		С	Monthly (200 Hours)
С		С	Quarterly (600 Hours
С	ZJ	С	Semi- annually (1200 Hours)
С	7J	С	Annually (2400 Hours)



Table 4. Wheel

Item	Inspecting Item	ТооІ	Daily (8 Hours)	Monthly (200 Hours)	Quarterly (600 Hours	Semi- annually (1200 Hours)	Annually (2400 Hours)
	Charged pressure	Tire Gauge	С	C	ဂ	ဂ	C
	Crack or damage		0	С	С	С	C
	Ground touchdown wearing condition			С	С	С	С
Tire	Abnormal wear condition	Depth Gauge	С	С	С	С	С
	Whether or not nail, stone, or other foreign substance present on tire			С	С	С	С
Tire Installa- tion	Whether or not nuts are loosened to be inspected	Detection Hammer	С	С	С	С	С
	Damage condition to be inspected		С	С	С	С	С
Wheel Rim Wheel Spoke	Damage condition of wheel rim, rim spoke, and Disc wheel		С	С	С	С	С



Table 4. Wheel (Continued)

Item	Inspecting Item	ТооІ	Daily (8 Hours)	Monthly (200 Hours)	Quarterly (600 Hours	Semi- annually (1200 Hours)	Annually (2400 Hours)
Axle Bearing	Loosening and noise to be inspected			С	С	С	С
	To be wiped up and refilled with lubricating oil					7J	Ω
Axle	Distortion, crack, and damage condition of axle body to be inspected			O	C	C	0



Table 5. Steering System

Item	Inspecting Item	ТооІ	Daily (8 Hours)	Monthly (200 Hours)	Quarterly (600 Hours	Semi- annually (1200 Hours)	Annually (2400 Hours)
	Clearance to be inspected		С	С	С	С	С
O cris	Axial loosening to be inspected		С	С	С	С	С
Wheel	Radial Loosening to be inspected		С	С	С	С	С
	Operating condition to be inspected		С	С	С	С	С
Steering Gear	Whether or not mounting bolts are loosened to be inspected			ဂ	೧	ဂ	C



Table 5. Steering System (Continued)

ltem	Inspecting Item	ТооІ	Daily (8 Hours)	Monthly (200 Hours)	Quarterly (600 Hours	Semi- annually (1200 Hours)	Annually (2400 Hours)
	Whether or not the king pin is loosened or damaged to be inspected			C	С	С	С
Steering Knuckle of Rear Axle	Bend, distortion, crack, or damage condition to be inspected			С	C	C	С
	Installation condition to be inspected	Detection Hammer		С	0	С	С
	Operating condition to be inspected		С	С	0	С	С
Steering Cylin- der	Whether or not leaks exists to be inspected		С	С	0	С	С
!	Whether or not loosening exists during installation to be inspected			С	C	C	C



Table 6. Brake System

Cable, etc.			Parking Brake Control		_	Broke Deda		Item
Whether or not connection is loosened	Control performance	Control performance	Whether or not brake is safe and reliable and brake stroke is enough	Whether or not air present in brake line	Operating condition	Pedal stroke	ldle stroke	Inspection Item
						Diving Ruler		ТооІ
С	С	С	С	С	С	С	С	Daily (8 Hours)
С	С	С	С	С	С	С	С	Monthly (200 Hours)
C	С	С	С	С	С	С	С	Quarterly (600 Hours
С	С	С	С	С	С	С	С	Semi- annually (1200 Hours)
С	ဂ	С	С	С	С	С	С	Annually (2400 Hours)



Table 6. Brake System (Continued)

	Wheel Cylin- der	Brake Master Cylinder and			Lines		Item
Master cylinder and wheel cyl- inder leakage and damage condition	Wear or damage condition of master cylinder and wheel cylinder	Master cylinder and wheel cylinder action condition	Oil level to be inspected for oil replacement	Leakage condition	Connecting and clamping parts, or loosening condition	Damage, leakage, and cracks	Inspection Item
							ТооІ
			С				Daily (8 Hours)
			С	C	С	С	Monthly (200 Hours)
			С	С	С	С	Quarterly (600 Hours
			R	С	С	С	Semi- annually (1200 Hours)
Z	С	С	R	C	С	С	Annually (2400 Hours)



Table 6. Brake System (Continued)

		Shoe	Brake Drum				Item
Wear and injury condition of brake drum	Whether or not operating time interval of automatic regulating device is proper to be inspected	Damage condition of return spring	Whether or not fixed pin is rusted	Condition of brake show action	Wearing condition of friction plate	Whether or not mounting parts of brake drum are loosened	Inspection Item
		Diving ruler			Vernier Calipers	Detection Hammer	ТооІ
							Daily (8 Hours)
						С	Monthly (200 Hours)
						С	Quarterly (600 Hours
						С	Semi- annually (1200 Hours)
С	C	С	С	С	С	С	Annually (2400 Hours)



Table 6. Brake System (Continued)

Item	Inspection Item	Tool	Daily (8 Hours)	Monthly (200 Hours)	Quarterly (600 Hours	Semi- annually (1200 Hours)	Annuall (2400 Hours)
	Whether or not bottom plate is distorted						C
Brake Bottom Plate	Whether or not cracked						0
	Whether or not loosening exists during installation						C



Table 7. Lifting System

Crack and wear condition of	Damage and wear condition of positioning pin	Damage, distortion, and wear condition of forks	Item Inspection Item T
			ТооІ
		С	Daily (8 Hours)
O		С	Monthly (200 Hours)
n	С	С	Quarterly (600 Hours
O	С	С	Semi- annually (1200 Hours)
C	С	С	Annually (2400 Hours)



Table 7. Lifting System (Continued)

Whether or not welding of forks is under poor connecting	Carriage Whether or not welding of inside/outside mast is under poor connecting condition, cracked or damaged	Whether or not welded place of tilting cylinder bracket and mast is under poor connecting condition, cracks, or damaged	Whether or not welded place on inside mast/outside mast and cross beam is cracked or damaged	Item Inspection Item
Whether or not welding of forks is under poor connecting condition, cracked or dam-	elding of st is under ondition, ed	elded place racket and r connecting or damaged	elded place tside mast s cracked or	
				ТооІ
				Daily (8 Hours)
C	С	С	С	Monthly (200 Hours)
C	С	С	С	Quarterly (600 Hours
C	С	С	С	Semi- annually (1200 Hours)
C	С	С	С	Annually (2400 Hours)



Table 7. Lifting System (Continued)

	Carriage (Continued)	Mast Fork			Item
Crack and damage condition of roller and roller shaft	Whether or not bolts for bottom of lifting cylinder, bolts for head of piston rod, u-bolts, and bolts for guide rail of walking beam are loosened	Whether or not bolts for support cover of mast is loosened	Wear and damage condition of bearing brush for mast	Whether or not roller is loosened	Inspection Item
					Tool
					Daily (8 Hours)
С	0	С		0	Monthly (200 Hours)
C				С	Quarterly (600 Hours
C	С	С		С	Semi- annually (1200 Hours)
C	C	С	С	С	Annually (2400 Hours)



Table 7. Lifting System (Continued)

ltem	Inspection Item	Tool	Daily (8 Hours)	Monthly (200 Hours)	Quarterly (600 Hours	Semi- annually (1200 Hours)	Annually (2400 Hours)
	Tensioning condition, whether or not distorted, damaged, or rusting of chain to be inspected		С	С	С	С	С
	Oil to be added to chain			С	С	С	0
Sprocket	Riveted pin and loosening condition			С	С	С	С
	Sprocket distortion and damage condition			С	С	С	С
	Whether or not chain sprocket bearing is loosened			С	С	С	С
Attachments	Whether or not condition is normal to be inspected			С	С	С	С



Table 7. Lifting System (Continued)

2 2 2	Hydraulic		200	Lifting Cylin-		Item
Wearing condition of driving gear for hydraulic pump	Whether or not oil leak or noise exists with hydraulic pump	Wear and damage condition of pin and cylinder steel-backed bearing	Leakage condition	Operating condition	Whether or not piston rod, piston rod thread, and connection Hammer are loosened, as well as distortion and damage condition	Inspection Item
					Detection Hammer	ТооІ
	С		С	С	С	Daily (8 Hours)
C	С	С	С	С	С	Monthly (200 Hours)
С	С	С	С	С	С	Quarterly (600 Hours
С	С	С	С	С	С	Semi- annually (1200 Hours)
C	С	С	С	С	C	Annually (2400 Hours)



Table 8. Hydraulic System

ltem	Inspection Item	ТооІ	Daily (8 Hours)	Monthly (200 Hours)	Quarterly (600 Hours	Semi- annually (1200 Hours)	Annually (2400 Hours)
	Oil quantity to be inspected, or oil to be replaced		С	С	С	С	0
Hydraulic Oil Tank	Suction oil filter core to be cleaned up					С	0
	Foreign substance to be removed					С	0
Return Oil Fil- ter	Return oil filter to be replaced					R	R
Control Valve	Whether or not connection is loosened		С	С	С	С	0
000	Operating condition		С	0	C	ဂ	C



Table 8. Hydraulic System (Continued)

	Line Joint		Multi-way Valve		ltem
Line to be replaced	Leakage, loosening, crack, distortion, or damage condition	Safety valve pressure to be measured	Operating condition of safety valve and tilting auto-locking valve	Oil leakage	Inspection Item
		Oil Pres- sure Gauge			ТооІ
	C			С	Daily (8 Hours)
	C		С	С	Monthly (200 Hours)
	C		С	С	Quarterly (600 Hours
	C	С	С	С	Semi- annually (1200 Hours)
R 1-2 Years	C	С	С	С	Annually (2400 Hours)



Table 9. Electrical System

		0	(Gasoline	- E J			Item
Wear and injury condition of center part for distributor	Whether or not distributor is burned out	Mounting condition of cover and HP wire	Cleaning the clearance of spark plug	Adjusting the clearance of spark plug	Whether or not spark plug is burned out	Whether or not distributer cap is cracked	Inspection Item
				Feeler Gauge			ТооІ
							Daily (8 Hours)
							Monthly (200 Hours)
			С	С		С	Quarterly (600 Hours
			С	С		С	Semi- annually (1200 Hours)
С	С	С	С	С	С	С	Annually (2400 Hours)



Table 9. Electrical System (Continued)

Item	Inspection Item	ТооІ	Daily (8 Hours)	Monthly (200 Hours)	Quarterly (600 Hours	Semi- annually (1200 Hours)	Annually (2400 Hours)
Ignition Device (Gasoline	Ignition Device Filling lubricating oil to rotating (Gasoline shaft				С	С	С
Engine) (Continued)	HP wire breakage condition						C
Start Motor	Pinion meshing condition				С	С	С
Rottory.	Electrolyte volume and clean-ing			С	С	С	С
Datterly	Inspecting specific weight of electrolyte				С	С	C
Flootric Wire	Wire harness injury and loosening condition			С	С	С	С
Ligotilo AAII d	Loosening condition of connection for electric circuit				C	C	C

Table 10. Seat, Frame, and Oil

Item	Inspection Item	ТооІ	Daily (8 Hours)	Monthly (200 Hours)	Quarterly (600 Hours	Semi- annually (1200 Hours)	Annually (2400 Hours)
Seat	Whether or not bolts are damaged or loosened to be inspected					С	С
	Whether or not truck frame and crossbeam are damaged or cracked						С
Frame	Whether or not rivets or bolts are loosened	Detection Hammer					С
	Repaired place to be inspected, if required		С	С	С	С	С
	Comprehensive inspection						С
Lubricating Grease to be Added or Oil	Lubricating condition of underpan to be inspected after cleaning	Grease Gun	С	С	С	С	С
to be Replaced	Oil in tank to be inspected						C



- When oil is different from that specified for this truck, its replacement cycle cannot be the same as that specified in this Manual. In this situation, the time for replacement should be shortened by ½ or 1/4 compared with the time specified in this Manual.
- Though high-viscosity oil has a wide operating temperature range, frequent replacement is still required. The additive will slowly deteriorate, viscosity will be lowered, and it will damage the hydraulic system severely at the time of high temperature.



Hoisting, Handling, and Towing of Forklift Truck

Hoisting Forklift

forklift using lifting device. Refer to the decal for exact beam and on the holes of the counterweight, then hoist the hoisting locations Tighten the cable on the two end holes of the outer mast



WARNING

- Do not wrap the cable around the overhead guard when litting.
- The cable and lifting device should be strong and heavy enough to sustain the forklift.
- Do not hoist the forklift through the driver cabin (Overhead Guard).
- Do not stand or go anywhere under the hoisting

Handling

distance transport. When the forklift truck need to be short distance transport. It is not suitable means for long Forklift is normally used in loading/unloading cargos and

> must be firmly fastened. forklift must be supported with wedges and the forklift body do the transport. To avoid displacement, the tires of the with 5 Tons and above rated capacity must be prepared to moved to a long distance, vessels, trains and heavy trucks

Towing

to start towing. the forklift. Tie the cable around the pin and reinstall the pin The tow pin under the counterweight is set for traction of

the truck ambient traffic and hang a seeable Being Towed mark on park brake and set the gear to neutral. Pay attention to the Method of traction after forklift being damaged: release the





WARNING

- Do not apply traction to forklifts that have problems with steering system or damaged brake system.
- Do follow the traffic rules when applying traction of the forklift trucks
- Do not tie the cable to locations unadvised.



Do not place or apply abrupt force on the cable.





- 1. The towed lift truck must have an operator.
- 2. Tow the lift truck slowly.

Maintenance



- 3. Using a lift truck or a lifting device that can be attached to the mast (i.e., come-a-long), raise the carriage and forks approximately 30 cm (12 in.) from surface, Install a chain around a mast crossmember and the carriage, to prevent carriage and mast channels from moving.
- 4. If another lift truck is used to tow the disabled lift truck, that lift truck must have an equal or larger capacity than the

disabled lift truck. Install approximately ½ of a capacity load on the forks of the lift truck that is being used to tow the disabled lift truck. This ½ capacity load will increase the traction of the lift truck. Keep the load as slow as possible.



Miscellaneous

Drawing of Lubrication System






Table 11. Oils Used for Forklift Truck

3# Lithium Base Lubricating Grease Drop Point 170	Lubricating Oil
ZSM207 DOT3 Synthetic Brake Fluid	Brake Fluid
85W/90	Gear Oil
6# Hydraulic Drive Oil	Hydraulic Drive Oil
L-HM32	Hydraulic Oil
Diesel Engine: GB11121-2006 standard requirements and the tough degree of its working conditions.	
To be selected and used according to engine operation and maintenance manual, or according to Gasoline Engine: GB11121-2006	Lubricating Oil
Summer 0# Winter -10~-35#	
TO be selected and used in accordance to diesel engine operation and maintenance manual, or according to GB252-2015 Light Diesel Oil.	Diesel Oil
92#	Gasoline
Brand or Code (Domestic)	Name

- It is recommended to use Kunlun brand oil products.
- Oil products of different brands cannot be blended in use.




_abels

tation of the label on your truck. **NOTE:** Label in the manual may not be an exact represen-

tact your Yale dealer to immediately replace any labels tion about possible hazards. It is important that all safety Safety labels are installed on your lift truck to give informathat have fallen off or are no longer legible labels are installed on the lift truck and can be read. Con-

Warning Label No One On or Under the Forks

WARNING



Label of Notices for Use

Attention

To make the truck and you safety, operator should obey these rules below city chanaged or objection, you could not operate it until repaired it Libeliere starting trock you should check all control and alarm device, if there are LOnly trained and authorized operator thall be permitted to operate the troof

in the load entirely and well proportioned. It is not permitted use only one fork to d. When carry the load, the weight should not much overload. The tork shall insert

You should operate the truck smoothly when start, turning, travel, brake and Load travel should lower the goods down and tilt the mast backwards urking. On a slick or wet road, you should decrease speed when namin

side curefully when traveled on a grade. If the slope angle is bigger than 10%, rarel forward up slope and backward down slope. Never turn sideways and stack

Notice the foot passenger, barrier, pothole and the clearance upods of up a man or standing on the fork

0.Do not carry the load unpackaged. Be carefully to carry these goods with large

9.No permitted to operate the truck or attachment on other position except the

1. Notice the load not drop from the load bracket for those tracks that overall m lift beight is higher than 3 meters. If necessary, make some protective

12.When leaving the truck, you should let the fork down, make the shift lever estral shut down the engine and cut the power. Parking on a grade, make sure to ghten the brake lever. If necessary, use a block when parking on a grade for a

4.Before driving over a dock-board or bridge-plate, be zure that it is properly (3. Travel with load as lew as possible and fift back the mast aith to sustain the weigh

6.The truck with attachment; should be treated at a loaded truc!

S. Make sure that there is no naked flame near the area, never smoke. The drives


BM990191

Maintenance




Data Plate for Fork Loading and Unloading Truck

ATTENTION



BO990168




BO990169




Label for Load Curve Diagram (Demonstration)

ATTENTION



Label for Parking Brake Adjustment ATTENTION







Label for Adding Hydraulic Oil NOTE










Label for Lifting

ATTENTION



WARNING

Mast

Label Do Not Stand Near or On Any Part of




BM990200




Label for No Riders

ATTENTION



BM990201

WARNING **Mast Warning Label - Crush Point**




BM990202




Label for Filling Fuel

NOTE (Diesel)



BM990203

NOTE (Gasoline)



BM990204



Label for Fan Safety

WARNING



BM990206

Operator Restraint and Tip-Over Warning Label

WARNING



BM990207




Label for Seatbelt

ATTENTION





BM990208



BM990209



Maintenance Register

NO MATTER HOW YOU SAY IT . . .

La Sécurité Ça Se Paye
La Seguridad Compensa
Betriebssicherheit Macht Sich Bezahlt
Passaa Oll Huolellinen
Veiligheid Voor Alles
Säkerhet Först
Essere Sicuro Paga
Seguranca Paga
Sikkerhet Først
Pinter Be Awas



نى التائن السلامة

校全部上

OPERATING MANUAL

GLP/GDP20UX-35UX (A7S1) Internal Combustion Counterbalanced Forklift Truck

PART NO. 550216339

1/20