

SAFETY/RISK/HAZARD ASSESSMENT

PLANT INFORMATION

NHG Ref/Part No.	LT01, 02, 03, 04
Plant ID:	
Plant Name:	Light Tower (Diesel)
Operator Competency:	Plant Licence Not Required

IS YOUR VEHICLE CAPABLE OF TOWING THIS TRAILER?

It is the drivers responsibility to check vehicle manufacturers towing specifications for braked and unbraked maximum loadings and are adhered to. This also includes all on road legal requirements.



Protective
equipment
must be worn
when operating
this machine



RISK ASSESSMENT INFORMATION

Potential Hazard(s)

Accident

Risk Level	Medium
Control Measures	Towbar connection to be checked to ensure ball location is complete, locking pin is in place, chain is connected and jockey wheel raised. Ensure unit is positioned on ground that is dry and solid Ensure brake has been applied and support legs extended Be vigilant and assess prevailing weather conditions, make sure wind is not excessive

**Please refer to the User Guide and Operators Manual
for detailed Operating Instructions**

The safety information contained in this assessment is general information only and should not be relied upon as a substitute for professional advice or tuition, which the hirer should seek before operating.