

SAFETY/RISK/HAZARD ASSESSMENT

PLANT INFORMATION

NHG Ref/Part No.

LoaKrt

Plant ID:

Plant Name:

Potential Noise Level in Db:

Required hearing protection class: 2

Operator Competency:

Plant Licence Not Required

It is the hirer's responsibility to ensure that all operators are competent.

Please refer to the User Guide and Operators Manual for detailed Operating Instructions



Protective
equipment
must be worn
when operating
this machine



RISK ASSESSMENT INFORMATION

Potential Hazard(s)

Crush injury

Risk Level Medium

Control Measures Keep unauthorised persons away from site

Establish a 4 meter exclusion zone around the local working area and ensure no person other than the operator, enters this zone whilst the machines engine is running.

Do not place any article or body part under the trencher at any time.

Electrocution

Risk Level Medium

Control Measures Do not carry out maintenance of any type whilst the rotary tiller is attached to the loader or any other power source.

**Please refer to the User Guide and Operators Manual
for detailed Operating Instructions**

The safety information contained in this assessment is general information only and should not be relied upon as a substitute for professional advice or tuition, which the hirer should seek before operating.