



NORTHERN HIRE GROUP

170 KVA Generator Set up / Start up Instructions

Scope of Works

SET UP

Place generator and fuel pod on a clear, stable level site

1. *Check all OIL, WATER and FUEL levels are correct*
2. *Connect the fuel line marked with the RED taped ends to the low RED taped fitting under the fuel pod and low RED fitting in the left hand side door of generator*
3. *Connect the fuel line marked with the WHITE taped ends to the high WHITE taped fitting on top of the fuel pod and high WHITE fitting in the left hand side door of generator*
4. *When the generator is not in use please make sure the yellow shut off valve under the fuel pod is in the off position.*
5. *Install temporary fencing securely around generator and fuel pod*

START UP

1. *Check all OIL, WATER and FUEL levels are correct*
2. *Make sure the yellow shut off valve under the fuel pod is in the on position.*
3. *Unplug or turn off any power load*
4. *Turn on the RED isolating switch above the batteries in the right hand side door*
5. *Open the End door and turn the BLUE nob to Manual (Wait 5/10 sec) and generator will automatically start.*
6. *Secure temporary fencing around generator and fuel pod*

SHUT DOWN

1. *Unplug or turn off any power load*
2. *Wait 1 min open the End door and turn the BLUE nob to OFF and generator will stop.*
3. *Turn OFF the RED isolating switch above the batteries in the right hand side door*
4. *When the generator is not in use please make sure the yellow shut off valve under the fuel pod is in the OFF position.*
5. *Secure temporary fencing around generator and fuel pod*