



FG Wilson 55kVA Generator Operating Procedure

Please refer to Towing – Trailer data sheet for safe towing procedure

Please refer to Pre-Start Procedure prior to operating this equipment

Use **DIESEL** fuel only.

Ensure all electrical devices are turned off or unplugged prior to starting generator.

1. **To start unit:**

- a) Engage Battery Isolator Switch
- b) Press the GREEN button to start
- c) Allow engine to warm for 1-2 minutes before operating

NOTES:

- **Do not overload** the unit by attempting to power an appliance beyond the output capabilities of the generator
- Use heavy duty extension cables specifically rated to suit the output of the generator.
- **Test the operation of the safety switch** before connecting any appliance
If the safety switch trips off, disconnect the faulty appliance and have it checked

2. **To stop unit:**

- a) Press the RED stop button. Engine will shut down after and automatic timed cool-down period.

Refer to Northern Hire Group Pty Ltd's General Electrical Safety Guide to reduce the risk of damage to property and/or equipment, injury or death.

Please report all faults, signs of wear/damage, leaks, or any other maintenance issue immediately to Northern Hire Group Pty Ltd personnel.

Do not consent to, or attempt any repair without authorisation from Northern Hire Group Pty Ltd.