



General air tool warnings

- 1. Read and understand this entire manual before attempting assembly or operation.
- Read and understand all warnings posted on the tool and in this manual. Failure to comply with all of these warnings may cause serious injury.
- 3. Replace warning labels if they become obscured or removed.
- 4. Do not use this tool for other than its intended use. If used for other purposes, JET disclaims any real or implied warranty and holds itself harmless from any injury that may result from that use.
- Always wear approved safety glasses or face shield while using this tool. (Everyday eyeglasses only have impact resistant lenses; they are *not* safety glasses.)
- 6. Wear ear protectors (plugs or muffs) if the noise exceeds safe levels.
- 7. Wear gloves and protective clothing if operation produces sparks or flying particles. Gloves should be tight-fitting, without frayed fingers or hanging threads. Keep hands and body away from the working area of tool.
- 8. Do not operate an air tool continually at full throttle without a work load on the tool.
- 9. The air tool must be properly lubricated before operating.
- Never start a percussion type air tool (chipper, breaker, buster, etc.) without securing the tooling in the retainer and placing the tip against the work surface.
- 11. Do not operate air tool without its guards in place. Do not modify the tool.

- Do not operate this tool while tired or under the influence of drugs, alcohol, or any medication.
- Adopt a comfortable posture with proper balance, and maintain secure footing at all times. Non-slip footwear or anti-skid floor strips are recommended.
- 14. Do not wear loose clothing or jewelry. Confine long hair.
- 15. Excessive air pressure and too much free rotation may decrease life of the tool and may cause a hazardous situation.
- 16. Check air hoses for wear, and keep them away from heat and sharp edges. Repair or replace damaged air hose immediately. Do not carry tool by the air hose.
- 17. Air hose may cause tripping hazards; keep hose away from traffic areas.
- Do not use this tool near flammable objects, or in potentially explosive environments. Do not use near live electrical wires.
- Do not use power tools in damp or wet location, or expose them to rain. Keep work area well lighted.
- 20. Do not leave a connected tool unattended. When not in use, disconnect tool from air source.
- 21. Shut off air supply and discharge any residual pressure from tool before removing hose, making adjustments, changing accessories, or storing tool.
- Make sure tool is switched off, and your finger off the trigger, before connecting to air supply.
- 23. Remove adjusting keys and wrenches before turning on tool.
- 24. Keep visitors a safe distance from the work area. *Keep children away*.

- Give your work undivided attention. Looking around, carrying on a conversation and "horse-play" are careless acts that can result in serious injury.
- 26. Do not force a tool or attachment to do a job for which it was not designed. The right tool will do the job better and more safely.
- 27. Repetitive motions and/or exposure to constant vibration can be harmful to hands and arms. Take frequent breaks and relax hands during extended operation. Change posture to avoid discomfort or fatigue.
- Compressed air can be harmful if directed toward sensitive areas of the body, and may propel small particles caught in the air stream. Exercise proper caution.
- 29. Use only recommended accessories; improper accessories may be hazardous.
- 30. Maintain tools with care. Keep air tool clean and oiled for best and safest performance.
- Do not use combustible gases, carbon dioxide, oxygen or any bottled gas as an air source for the tool. These can present risk of explosion and serious injury.
- 32. Do not lubricate the tool with combustible liquids, such as kerosene, diesel or jet fuel.
- Do not dispose of this tool with normal household waste. Never dispose of the air tool into fire.

Specific warnings for Riveters

- 34. This tool is designed for inserting blind rivets into metal surfaces up to 3/16-inch thick. If you are not familiar with the proper and safe operation of a pneumatic riveter, do not use until proper training and knowledge have been obtained.
- 35. Do not operate riveter without safety cap installed, as mandrel may be expelled from the tool forcefully causing injury.
- 36. Do not install rivets close to the edge of a work surface, as it may cause workpiece to split, causing a safety hazard.
- 37. Make sure tool is cleared of spent mandrel before inserting new rivet into nosepiece.

 This tool is for inserting rivets into metal surfaces – do not use on soft surfaces.

A WARNING: This product can expose you to chemicals including lead which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to http://www.p65warnings.ca.gov.

WARNING: Some dust, fumes and gases created by power sanding, sawing, grinding, drilling, welding and other construction activities contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Some examples of these chemicals are:

- · lead from lead based paint
- crystalline silica from bricks, cement and other masonry products
- arsenic and chromium from chemically treated lumber

Your risk of exposure varies, depending on how often you do this type of work. To reduce your exposure to these chemicals, work in a well-ventilated area and work with approved safety equipment, such as dust masks that are specifically designed to filter out microscopic particles. For more information go to http://www.p65warnings.ca.gov/ and http:// www.p65warnings.ca.gov/wood.

Familiarize yourself with the following safety notices used in this manual:

AWARNING This means that if precautions are not heeded, it may result in serious, or even fatal, injury.

CAUTION This means that if precautions are not heeded, it may result in minor injury and/or possible tool damage.