



Pre-Start Procedure

Self-Propelled Slasher/Mower

Pre-start Procedure:

1. Inspect entire unit before each use. Report any damaged or worn parts to NHG.
2. Check for any signs of fluid leaks, and ensure all fasteners are in place and securely fastened.
3. Familiarise yourself with the machine controls. Locate emergency stop prior to starting engine.
4. Clear area to be mowed of all debris and obstacles.
5. Ensure area to be mowed and area of discharge is clear of other persons and pets. Maintain a 20m exclusion zone.

On starting, always allow the unit to 'warm up' before beginning works.